



Welcome to

The Dwayne Peaslee Technical Training Center

CDL Pre Behind-the-Wheel Training Course

March 2023





What You Will Learn In This Course

- How to properly conduct an A, B, and C Pre-trip Inspection
- How to perform an external light check
- How to perform a "Connections" inspection
- How to perform an In-Cab Inspection with Brake Check





Starting at the front of the truck, top to bottom. Pointing at the items say these phrases




- THE <u>HEADLIGHTS</u> ARE THE PROPER COLOR, CLEAR, AND NOT CRACKED, BROKEN, OR DIRTY
- THE TRUCK IS NOT LEANING, MEANING THERE ARE NO SUSPENSION OR TIRE PRESSURE ISSUES
- THE LOWER RADIATOR HOSE IS PROPERLY MOUNTED, NOT LEAKING AND ALL HARDWARE PRESENT









With the hood open, from the passenger side of the truck, pointing at the items say these phrases

 THE <u>COOLANT RESERVOIR</u> IS AT THE PROPER LEVEL, SECURELY MOUNTED, AND NOT LEAKING. THE HOSE IS NOT DAMAGED OR LEAKING AND IS SECURELY MOUNTED.

• THE <u>WATER PUMP</u> IS SECURELY MOUNTED AND NOT DAMAGED, NOT LEAKING AND IS BELT DRIVEN. THE BELT IS NOT CUT OR DAMAGED AND HAS NO LESS THAN ½" OF PLAY AND NO MORE THAN ¾" OF PLAY





With the hood open, from the driver's side of the truck, pointing at the items say these phrases

• THE ALTERNATOR IS SECURELY MOUNTED AND NOT DAMAGED, ALL WIRES ARE SECURE. THE BELT IS NOT CUT OR DAMAGED AND HAS NO LESS THAN ½" OF PLAY AND NO MORE THAN ¾" OF PLAY


 TO CHECK THE <u>OIL LEVEL</u>, REMOVE THE DIPSTICK WIPE CLEAN, RE-INSERT, REMOVE AND CHECK THE OIL LEVEL. LEVEL MUST AT, OR BELOW FULL, BUT ABOVE ADD

 THIS IS THE <u>POWER STEERING RESERVOIR</u> DIPSTICK. THE RESERVOIR IS AT THE PROPER LEVEL, NOT LEAKING AND IS SECURELY MOUNTED. THE HOSE HAS NO SPLITS OR CUTS, IS SECURELY MOUNTED AT BOTH ENDS, AND DOES NOT LEAK





With the hood open, from the driver's side of the truck, pointing at the items say these phrases



 THE <u>POWER STEERING PUMP</u> IS SECURELY MOUNTED AND NOT DAMAGED. THERE ARE NO LEAKS ON THE GROUND

 THE <u>STEERING SHAFT</u> IS SECURELY MOUNTED AND NOT CRACKED OR BROKEN AND HAS NO EXCESSIVE PLAY

THE <u>POWER STEERING BOX</u> IS SECURELY MOUNTED TO THE FRAME AND NOT DAMAGED. ALL HARDWARE IS PRESENT AND THERE ARE NO LEAKS





With the hood open, from the driver's side of the truck, pointing at the items say these phrases

 THE <u>PITMAN ARM</u> IS SECURELY MOUNTED, AND NOT CRACKED OR BROKEN. THE CASTLE NUTS AND COTTER PINS ARE PRESENT AND NOT DAMAGED

THE <u>DRAG LINK</u> IS PROPERLY SECURE AND NOT BROKEN OR CRACKED. THE RUBBER BUSHINGS HAVE NO DAMAGE

THE <u>UPPER AND LOWER CONTROL ARMS</u> AND TIE ROD ARE NOT BENT OR BROKEN AND ALL HARDWARE IS PRESENT AND SECURELY MOUNTED



With the hood open, from the driver's side of the truck, pointing at the item say these phrases



 THE <u>FRONT AND REAR SPRING MOUNTS</u> ARE SECURELY MOUNTED TO THE FRAME AND ARE NOT DAMAGED



 THE <u>LEAF SPRINGS</u> ARE NOT CRACKED, BROKEN, SCISSORING, OR MISSING

• THE <u>U-BOLTS</u> ARE NOT BROKEN, CRACKED, LOOSE OR MISSING





With the hood open, from the driver's side of the truck, pointing at the items say these phrases

THE SHOCK ABSORBERS ARE SECURELY MOUNTED AND NOT LEAKING.
THE RUBBER BUSHINGS ARE NOT WORN

• THE <u>AIR HOSE TO THE BRAKE CHAMBER</u> IS SECURELY MOUNTED ON BOTH ENDS. THERE ARE NO SPLITS OR CUTS AND IS NOT LEAKING

 THE <u>BRAKE CHAMBER</u> IS SECURELY MOUNTED. IT IS NOT CRACKED OR BROKEN AND HAS NO LEAKS





With the hood open, from the driver's side of the truck, pointing at the items say these phrases



- THE ABS LINE IS SECURELY MOUNTED AND NOT FRAYED
- THE <u>SLACK ADJUSTER</u> HAS NO BROKEN OR LOOSE PARTS. THE PUSH ROD IS AT A 90° ANGLE TO THE CHAMBER AND HAS NO MORE THAN 1" OF PLAY







With the hood open, from the driver's side of the truck, pointing at the items say these phrases

- THE <u>BRAKE PAD</u> IS SECURELY MOUNTED AND NOT BROKEN OR CRACKED. THE PAD MUST HAVE A MINIMUM OF 1/4" DEPTH WITH NO SIGNS OF CRACKING, GLAZING, GREASE OR OIL CONTAMINANTS
- THE <u>BRAKE DRUM</u> IS SECURELY MOUNTED. IT IS NOT CRACKED OR BENT AND HAS NO BLUEING FROM EXCESSIVE HEAT AND NO GREASE OR OIL CONTAMINANTS





With the hood open, from the driver's side of the truck, pointing at the items say these phrases

 THE <u>WHEEL</u> IS NOT DAMAGED, CRACKED, OR BENT INSIDE OR OUTSIDE. THERE ARE NO WELDS

- CHECK FOR PROPER <u>TIRE INFLATION</u> WITH AN AIR GAUGE
- THE <u>TIRE SIDEWALLS</u> HAVE NO SPLITS OR CUTS AND THE TREAD IS EVENLY WORN AND NOT A RETREAD









With the hood open, from the driver's side of the truck, pointing at the items say these phrases

• THE <u>VALVE STEM</u> IS SECURELY MOUNTED, NOT DAMAGED AND HAS A METAL CAP

 THE <u>LUG NUTS</u> ARE NOT CRACKED, BROKEN OR MISSING.
THERE ARE NO RUST TRAILS OR SHINY THREADS FROM LOOSE LUG NUTS

 THE <u>HUB SEAL</u> IS NOT CRACKED, BROKEN, OR LEAKING. THE OIL LEVEL IS ADEQUATE

